
ASSEMBLY INSTRUCTIONS




TOOLS REQUIRED



Hammer
(Not Included)



Philips Screwdriver
(Not Included)



2 - People Recommended

ASSEMBLY RATING



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # **22-05-09**

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all accounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**

  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS

Note :
Every cam lock bolt must have a cam lock connector in order to fasten the parts together.


cam bolt



cam lock


screwdriver




1

Screw the cam bolt into panel.




2

Insert the cam bolt into the bolt hole of joint panel.



3


Align the cam lock with its side opening (or arrow) pointing to cam bolt.




4

Turn the cam lock clockwise gently until it will not turn any more.

FLOATING TV CONSOLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS


Ⓐ1PC




Ⓑ2PCS



Ⓒ2PCS



Ⓓ1PC




Ⓔ1PC



HARDWARE

① 16PCS



② 16PCS

0.47"




③ 16PCS

0.98"

④ 6PCS

3.46"



ACCESSORIES

A1 6PCS



A2 20PCS

0.62"



A3 16PCS




A4 1PC




GET READY

Please group boards as below.


Ⓓ1PC



Ⓑ2PCS



Ⓒ2PCS



Ⓐ1PC



Ⓔ1PC





Body

ASSEMBLY INSTRUCTIONS


1

Hardware ① x 16PCS
Hardware ③ x 16PCS
Accessory A1 x 4PCS
Accessory A2 x 8PCS
Accessory A4 x 1PC






X 2



X 2





Apply a dab of glue into dowel holes of panels before inserting dowels (#3).


ASSEMBLY INSTRUCTIONS

2

Part Ⓑ x2PCS
Part Ⓒ x2PCS
Part Ⓓ x1PC
Hardware ②x 8PCS
Accessory A3 x 8PCS









3

Part Ⓐ x1PC
Hardware ②x 8PCS
Accessory A3 x 8PCS






ASSEMBLY INSTRUCTIONS

4

Accessory A1 x 2PCS

Accessory A2 x 4PCS




ASSEMBLY INSTRUCTIONS

5

To ensure wall mounted furniture is even, please use a leveler (not provided) as guidance.


This is the recommended distance for the height of the product. Draw a line at the desired height of the product by using a pencil.




6

Part Ⓔ x1PC

Hardware ④x 6PCS






Align panel (#E) to the line on the wall, then secure screws (#4) onto the holes of panel (#E) where the studs behind the wall is located at.


ASSEMBLY INSTRUCTIONS


7

Accessory A2 x 8PCS



Align the brackets of the TV-stand to the panel (#E) , then secure by using screws (#A2).






8



ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.