TOOLS REQUIRED



Phillips Screwdriver

(Not Included)



Hammer (Not Included)




2 - Persons Recommended

ASSEMBLY RATING



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.





	Are you missing anything?	Check out our Quick Tips!
	Double-check all parts, hardware and accessories listed on Page 6 are accounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
1 1	Should we send any replacements?	Prep Time!

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.






Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS

Note:

Every cam lock bolt must have a cam lock connector in order to fasten the parts together.









cam bolt

cam lock


screwdriver




Screw the cam bolt into panel.



Insert the cam bolt into the bolt hole of joint panel.



Align the cam lock with its side opening (or arrow) pointing to cam bolt.





Turn the cam lock clockwise gently until it will not turn any more.

TV STAND



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.





HARDWARE

(1) 32PCS (2) 32PCS (3) 18PCS (4) 3PCS (5) 16PCS
































0.78"










③









ACCESSORIES


(A1) 2PCS (A2) 2PCS (A3) 2PCS 90







A5 1PC










GET READY


Please group boards as below.







2









Part **(D)** x1PC Part **(S)** x1PC Hardware ⑤ x2PCS Accessory A5 x1PC Top Front **6 5** (5) 0 (A5) 10 (5) Hardware ⑤ x10PCS **(**5) Accessory A5 x1PC (5) 0 5 Front Top 0

11

Part (1) x1PC Part 1 x1PC

Hardware ② x10PCS Hardware ⑤ x2PCS

Accessory A5 x1PC Accessory (A6) x2PCS




Top▼

12

Part N x1PC Part x1PC

Part P x1PC

Hardware ② x2PCS



13 Hardware ② x4PCS Accessory (A4) x8PCS (A4) $\mathcal{O}_{\overline{A4}}$ $\mathcal{O}_{\overline{A4}}$ Front Top▼ (A4) 1

Hardware ② x4PCS Hardware (3 x4PCS A 13 O B Top X4 ⊾Front


15

Part ① x2PCS


Hardware ① x2PCS


Accessory A1 x2PCS Accessory A2 x2PCS Accessory A3 x2PCS





16





18



✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

