


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED




Allen Wrench

(Included)



**Phillips
Screwdriver**

(Not Included)



**2 - People
Recommended**

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING



Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.



Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!



Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!




Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.




Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.




Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



Save the instructions and store
any supplied tools for later
maintenance.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

TV TABLE




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

#1 1pc




Top

#2 1pc



Front Frame

#3 1pc



Bottom

#4 1pc



Right panel

#5 1pc



Left panel

#6 2pcs




Shelf

#7 1pc




Shelf

#8 1pc



Back panel

#9 2pcs




Back panel

#10 2pcs



Leg 30x30x45mm

TV TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.

HARDWARE

#A 10pcs




Bolt $\text{\O}1/4"$ x 35mm

#B 12pcs



Shelf Support

#C 10pcs



Flat Washer $\text{\O}5/16"$ x 19mm

#D 10pcs



Lock Washer $\text{\O}1/4"$

#E 1pc



Allen Wrench 4mm

#F 2pcs



$\text{\O}30\text{mm}$

#G 2pcs




Pan Head Bolt 4 x 32mm

#H 12pcs



Screw 3 x 12mm


Exploded View



ASSEMBLY INSTRUCTIONS


1

Part #3 x1pc
Part #10 x2pcs



2


Part #2 x1pc



ASSEMBLY INSTRUCTIONS


3

Part #8 x1pc
Part #9 x2pcs



4


Part #4 x1pc
Part #5 x1pc



ASSEMBLY INSTRUCTIONS

5


Part #8 x1pc
Part #9 x2pcs



Slide back panels (#8,9) to the grooves of the unit.

6

Part #1 x1pc
Hardware #A x10pcs
Hardware #C x10pcs
Hardware #D x10pcs
Hardware #E x1pc



Align top (#1) to the unit, then secure by using bolts (#A) with washers (#C,D).

ASSEMBLY INSTRUCTIONS

7

Part #6 x2pcs

Part #7 x1pc

Hardware #B x12pcs




Hardware #F x2pcs

Hardware #G x2pcs


Hardware #H x12pcs

Insert shelf supports (#B) to the desired height of the shelves (#6,7), then secure by using screws (#H).

Secure knobs (#F) to the doors by using bolts (#G).



8



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.