

ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED




Phillips Screwdriver

(Not Included)



Hammer

(Not Included)



2 - People Recommended

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING



Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.



Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!



Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!




Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS


Note :

Every cam lock bolt must have a cam lock connector in order to fasten the parts together.




1

Screw the cam bolt into panel.




2

Insert the cam bolt into the bolt hole of joint panel.



3

Align the cam lock with its side opening (or arrow) pointing to cam bolt.




4

Turn the cam lock clockwise gently until it will not turn any more.


FLOATING TV CONSOLE

- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS


A 1PC




E 1PC




I 1PC




M 1PC




B 1PC




F 1PC




J 1PC




N 1PC




C 1PC




G 1PC




K 1PC




D 1PC



H 1PC



L 2PCS



HARDWARE

① 16PCS ② 16PCS ③ 10PCS ④ 16PCS



1.97"

⑤ 2PCS ⑥ 4PCS ⑦ 2PCS ⑧ 2PCS



0.59"

0.39"

⑨ 2SETS



ACCESSORIES

A1 2PCS **A2** 4PCS **A3** 1PC **A4** 1PC **A5** 1PC



0.75"

A6 1PC **A7** 12PCS **A8** 12PCS **A9** 1PC **A10** 5SETS



1.38"

A11 5PCS




2.76"

(Light Hickory)


GET READY

Please group boards as below.


E 1PC




F 1PC




I 1PC




B 1PC




C 1PC




D 1PC




G 1PC




H 1PC



A 1PC




N 1PC




Body


J 1PC




K 1PC



L 2PCS



M 1PC



Doors
/Shelf

ASSEMBLY INSTRUCTIONS

1


Hardware ① x16PCS

Hardware ③ x4PCS

Hardware ⑤ x2PCS






Hardware ⑥ x4PCS

Accessory A9 x1PC



Attach magnet to panel
(#C) by using screws
(#6). Make sure magnet
(#5) is facing the direction
of the arrow.

X2








ASSEMBLY INSTRUCTIONS

2

Hardware ③ x6PCS
Hardware ⑦ x2PCS
Hardware ⑧ x2PCS
Hardware ⑨ x2SETS

Accessory A1 x2PCS
Accessory A2 x4PCS
Accessory A9 x1PC



ASSEMBLY INSTRUCTIONS

3

Part **E** x1PC


Part **F** x1PC

Part **I** x1PC


Hardware ④ x4PCS

Accessory **A6** x1PC

Accessory **A8** x4PCS



X4



4



Part **B** x1PC

Part **C** x1PC

Part **D** x1PC

Hardware ④ x8PCS

Accessory **A6** x1PC



ASSEMBLY INSTRUCTIONS

5


Part **G** x1PC

Part **H** x1PC

Hardware ④ x4PCS

Accessory **A6** x1PC

Accessory **A7** x12PCS



ASSEMBLY INSTRUCTIONS

6


Part A x1PC

Part N x1PC

Hardware ② x8PCS

Accessory A3 x1PC

Accessory A8 x8PCS



Please refer to page 5 for detailed instructions on how to fasten cam locks (#2) to cam bolts (#1).


Use the provided stickers (#A8) to cover exposed locks.

X8

ASSEMBLY INSTRUCTIONS

7


Hardware ② x2PCS



8

Part L x2PCS


Hardware ② x6PCS



ASSEMBLY INSTRUCTIONS

9

Part **J** x1PC
Part **K** x1PC



ASSEMBLY INSTRUCTIONS






For Mounting: ONLY use the SMALL pre-drilled holes for both Cement Wall and Drywall.
ONLY use the LARGE pre-drilled holes for Solid Wood Wall and Studs.

10

Part M x1PC


Accessory A4 x1PC

Accessory A5 x1PC




ASSEMBLY INSTRUCTIONS


11



Please refer to page 19
on wall mounts.



OR



Use power drill (not included) to drill
holes onto the marks on the wall.



ASSEMBLY INSTRUCTIONS

12

Accessory **A10** x5SETS

Accessory **A11** x5PCS

Use provided screws (#A10) and anchors to secure part (#M) onto Cement Wall/DryWall.





Secure part (#M) onto the wall using (#A10). Please ensure the orientation of part (#M) and is properly leveled/aligned to the wall. Refer to page 19 on wall mounting guide.

X5

OR

Use provided wood screws (#A11) to secure part (#M) onto Solid Wood Wall or STUDS.




Secure part (#M) onto the wall using (#A11). Please ensure the orientation of part (#M) and is properly leveled/aligned to the wall. Refer to page 19 on wall mounting guide.

X5

ASSEMBLY INSTRUCTIONS

13




14

ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.


ASSEMBLY INSTRUCTIONS

Wall Mounting and Fixing



EXPANSION WALL ANCHOR

Our provided expansion wall anchors are only suitable for masonry walls, such as drywall, plaster or concrete, and are best for holding lightweight items or for anti-tip prevention. If you are unsure of the correct wall anchor to use with the product, please request professional guidance. Liability for product damage or failure due to using the incorrect anchors will fall on the installer.




CHECK BEFORE PROCEEDING


Prior to drilling or hammering, please check for wires or pipes. We recommend using a stud finder to locate a stud, which will offer more appropriate resistance and hold more weight.

QUICK TIPS


1. If unsure of the proper size, always choose a larger screw and wall anchor.




2. Match the drill bit to the wall anchor and hole size.



3. Only drill horizontally. Do not force the drill or enlarge the hole for the wall anchor.



4. Take extra care when drilling into high walls or ceramic tiles. Wall anchors should be a tight fit for the hole. Never use wall anchors in ceilings.



MAINTENANCE

Yearly
Check

We recommend a yearly check to see if the wall anchor or screw has loosened. If so, please remove the existing wall anchor and screw, and use a new anchor.