


ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED



Allen Wrench

(Included)



Phillips
Screwdriver

(Not Included)



2 - People
Recommended

ASSEMBLY RATING



EASY ————— DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.





Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



Save the instructions and store
any supplied tools for later
maintenance.


After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN
OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS
INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




PARTS

#1 1pc




Upper Right Frame

#2 1pc




Upper Left Frame

#3 1pc




Lower Right Frame

#4 1pc




Lower Left Frame

#5 1pc




Shelf 1

#6 1pc




Shelf 2

#7 1pc




Shelf 3

#8 1pc



Shelf 4

#9 1pc



Smoking box

HARDWARE

#A 4pcs



Bolt Ø1/4" x 1-3/8"

#B 16pcs



Bolt Ø1/4" x 2-3/8"

#C 16pcs




Barrel Nuts Ø1/4"

#D 1pc



Allen Key 4mm

#E 4pcs



Wood Dowel Ø10 x 40mm

#F 4pcs



Screw #4 x 35mm

#G 2pcs



Screw #3 x 15mm

#H 4pcs



Flat Washer Ø4 x 10mm

#I 2pcs




Screw #3.5 x 20mm

#J 2pcs




Tox

#K 2pcs



Fabric



ASSEMBLY INSTRUCTIONS

1) Align lower right and left frames (#3,4) to the shelf (#8) and smoking box (#9). Secure frames (#3,4) to shelf (#8) by using bolts (#B) with barrel nuts (#C).

1

Part #3 x1pc

Part #4 x1pc


Part #8 x1pc

Part #9 x1pc

Hardware #A x4pcs

Hardware #B x4pcs

Hardware #C x4pcs



2

Part #1 x1pc

Part #2 x1pc

Part #5 x1pc


Part #6 x1pc

Part #7 x1pc

Hardware #B x12pcs

Hardware #C x12pcs


Align upper right and left frames (#1,2) to shelves (#5,6,7), then secure by using bolts (#B) with barrel nuts (#C).



ASSEMBLY INSTRUCTIONS

3


Hardware #E x4pcs
Hardware #F x4pcs



Insert dowels (#E) to holes of the lower frames (#3,4), then align the upper frames (#1,2) to the lower frames (#3,4). Secure by using screws (#F).

4



Detach handle from the inside of drawer, then secure handle to the outside of drawer.



ASSEMBLY INSTRUCTIONS


5

Hardware #G x2pcs
Hardware #H x4pcs
Hardware #I x2pcs
Hardware #J x2pcs
Hardware #K x2pcs



- 1) Align strap (#K) to top back corners of the product, then secure by using screws (#G) with washers (#H).
- 2) Align and measure product with strap to the wall, then drill a hole in the wall. Insert plastic inserts (#J) to the hole of the wall, then align strap (#K) to plastic inserts (#J). Secure by using screws (#I) with washers (#H).

6



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.


ASSEMBLY INSTRUCTIONS

Wall Mounting and Fixing



EXPANSION WALL ANCHOR

Our provided expansion wall anchors are only suitable for masonry walls, such as drywall, plaster or concrete, and are best for holding lightweight items or for anti-tip prevention. If you are unsure of the correct wall anchor to use with the product, please request professional guidance. Liability for product damage or failure due to using the incorrect anchors will fall on the installer.




CHECK BEFORE PROCEEDING


Prior to drilling or hammering, please check for wires or pipes. We recommend using a stud finder to locate a stud, which will offer more appropriate resistance and hold more weight.

QUICK TIPS


1. If unsure of the proper size, always choose a larger screw and wall anchor.




2. Match the drill bit to the wall anchor and hole size.



3. Only drill horizontally. Do not force the drill or enlarge the hole for the wall anchor.



4. Take extra care when drilling into high walls or ceramic tiles. Wall anchors should be a tight fit for the hole. Never use wall anchors in ceilings.



MAINTENANCE

Yearly
Check

We recommend a yearly check to see if the wall anchor or screw has loosened. If so, please remove the existing wall anchor and screw, and use a new anchor.