


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT

Tools Required For Assembly:

Allen Wrench



(Included)

Phillips Screwdriver



(Not Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.









FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.













Before you begin, please read Page 2 of "Assembly and Care Advice".


And remember, do not tighten until each step is completed or instructed.

Parts List

	#1 x 1pc Left Side Panel		#4 x 1pc Top Panel
	#2 x 1pc Right Side Panel		#5 x 1pc Bottom Panel
	#3 x 1pc Glass Door		#6 x 4pcs Glass Shelf

Hardware List


	#A x 12pcs Cam-Bolts		#F x 23pcs Screws
	#B x 12pcs CAM-LOCK		#G x 1pc Handle
	#C x 12pcs Wood Dowel		#H x 1pc Handle Bolt
	#D x 10pcs Glass Support		#I x 1pc Glue
	#E x 1pc Light		#J x 3pcs Hing




#K x 2pcs
Small Clamp



#O x 1pc
Plastic Line




#L x 2pcs
Large Clamp



#P x 1pc
Large Screw



#M x 1pc
Plug






#Q x 1pc
Short Screw




#N x 2pcs
L Metal




#A x 4pcs
#F x 2pcs
#L x 1pc



#A x 4pcs
#F x 2pcs
#L x 1pc



#A x 4pcs




#E x 1pc
#F x 3pcs




Insert cam-locks (#B) into the pre-drilled holes along the sides of the right side panel (#2). Insert wood dowels and pply glue (#I) onto the wood dowels (#C). Then insert the right side panel (#2) onto the wood dowels (#C) and cam-bolts (#A). The cam-bolts will be inserted into the cam-locks (#B). Using a Phillips screw driver tighten the cam-locks until you feel resistance. Over tightening the cam-locks may break them.

#B x 4pcs
#C x 4pcs
#I x 1pc



Insert cam-locks (#B) into the pre-drilled holes along the sides of the left side panel (#1) and right side panel (#2). Insert wood dowels (#C) and apply glue (#I) onto the wood dowels (#C). Then insert the left side panel (#1) and right side panel (#2) onto the wood dowels (#C) and cam-bolts (#A) located on the top and bottoms panels (#4,5). The cam-bolts will be inserted into the cam-locks (#B). Using a Phillips screw driver tighten the cam-locks until you feel resistance. Over tightening the cam-locks may break them.


#B x 8pcs
#C x 8pcs
#I x 1pc





- I. Determine exactly where you want to drill a hole and mark the spot(s). Be sure that you hold the drill perpendicular to the wall so that the anchor will sit parallel. You should drill a hole that is approximately the same size as the plug (#M) itself. Insert plug.
- II. Align one L metal (#N) to the plug and insert a large screw (#P). Secure using a Phillips screwdriver.
- III. Align another L metal (#N) to the pre-drilled hole on the top panel and insert a small screw (#Q). Secure using a Phillips screwdriver.
- IV. Insert one end of the plastic line (#O) into both L metals and tighten.

#D x 10pcs
 #O x 1pc
 #P x 1pc
 #Q x 1pc
 #M x 1pc
 #N x 2pcs





- I. Align the hinges to the pre-drilled holes along the right side. Insert screws (#F) and secure using a Phillips screwdriver.
- II. Align the small clamps (#K) to the top and bottom sides of the glass door (#3). Insert screws (#F) and secure using a Phillips screwdriver.
- III. Insert handle bolt (#H) into the pre-drilled hole along the side of the glass door (#3). Insert the handle (#G) onto the other side of the bolt and secure using a Phillips screwdriver.

#F x 16pcs
#H x 1pc
#J x 3pcs
#K x 2pcs

