


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT

Tools Required For Assembly:

Allen Wrench



(Included)

Phillips Screwdriver



(Not Included)




2 PERSONS RECOMMENDED

ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY.
PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".


And remember, do not tighten until each step is completed or instructed.

Parts List

	#1 x 1pc Headboard (Left)
	#2 x 1pc Headboard (Right)
	#3 x 1pc Guardrail
	#4 x 1pc Side Rail
	#5 x 1pc Front Trundle Panel
	#6 x 1pc Rear Trundle Panel
	#7 x 2pcs Side Trundle Panel
	#8 x 2set Twin Slat Kit (13pcs)


Hardware List

	#A x 8set Bolt & Barrel Nut
	#B x 8pcs Bolt 1/4" x 1-3/16"
	#C x 2pcs Screw 1/4" x 4"
	#D x 52pcs Screw 3/16" x 1-3/16"
	#E x 8pcs Screw 3/16" x 3/4"
	#F x 4pcs Wheel
	#G x 2pcs Wood Dowel 7/16"x1-9/16"
	#H x 1pc Allen Wrench 4mm




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.






#A x 4set
#C x 2pcs



2) Secure top holes by using bolts (#C).




1) Align guardrail (#3) to the holes of the headboards (#1,2). Insert barrel nuts to the holes in the back of the guardrail (#3). Secure bottom holes by attaching bolts (#A) to barrel nuts.



#A x 4set


Align side rails (#4) to the holes of the headboards (#1,2). Insert barrel nuts to the holes of the side rails (#4). Secure by attaching bolts (#A) to the barrel nuts of the side rail (#4).






Align twin slat kit (#8) to the side rails of the day bed. Secure by using screws (#D).

#D x 26pcs



#G x 2pcs




Insert dowels (#G) to the bottom hole of the headboard (#1,2).




Align front and rear trundle panels (#5,6) to the holes of the side panels (#7), then secure with bolts (#B).

#B x 8pcs



Align twin slat kit (#8) to the front and rear trundle panels (#5,6), then secure with screws (#D).




#D x 26pcs





#7
#E x 8pcs
#F x 4pcs

Align the wheels (#F) to the bottom corners of the trundle.
Secure by using screws (#E). There will be no pre-drilled
holes.



ASSEMBLY IS COMPLETED