

TOOLS REQUIRED




Allen Wrench

(Included)



Phillips Screwdriver

(Not Included)



2 - People Recommended

ASSEMBLY RATING



EASY — DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed are all acccounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CHEST



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS






Top Panel





Bottom Panel





Drawer Bottom Panel



1pc



Middle Divider Panel





Left Side Panel





Drawer Front Panel



4pcs



Drawer Back Panel





Right Side Panel





Drawer Left Side Panel



4pcs



Legs





Back Panel







Drawer Right Side Panel





Divider Panel



Exploded View









Attach wooden dowels (#C) to L/R side panels (#2, #3).

3
Hardware #Ox 4pcs




4
Part #5 x 1pc
Part #11 x 4pcs

Attach legs (#11) to the Bottom Panel (#5).



Align and attach Bottom board (#5) to the L/R side panels (#2,3).


5



6


Part #1 x1pc

Attach Top panel (#1) onto L/R side panels (#2,3). Lock into place.




Part #4 x 2pcs
Hardware #Dx 16pcs

Align back panel (#4) and secure using Bolts (#D).




8
Hardware#D x2pcs



9

Part #6x1pc Part #7x1pc Part #8x1pc




10

Part #9 x 1pc Part #10 x 1pc


Hardware #Dx 4pcs

Insert Drawer bottom panel (#9). Then align Drawer back panel (#10) and secure using Bolts (#D).



x 4

11



12

